



# User Guide Vivo Nordic

## **FEATURE LIST**

- Flash Function
- Pause Function
- Last Number Redial
- Tone Dialing Mode
- Desktop/Wall Mounting Selection

## **OPERATION**

### **MAKING CALLS AS A NORMAL TELEPHONE**

Pick up the handset you will hear a dial tone.  
Dial the number you want to call.

### **RECEIVING CALLS AS A NORMAL TELEPHONE**

When your phone rings, simply pick up the handset and speak into the mouthpiece of the handset. Hang up the handset on the Base unit to release the telephone line when finish conversation.

### **LAST NUMBER REDIALING**

Pick up the handset you will hear a dial tone.  
Press the REDIAL key, telephone will dial the last number dialed.

### **USING FLASH BUTTON**

Press FLASH button replaces the hook switch when using features such as call waiting and call forwarding.

### **HOLD FUNCTION**

To place a call on Hold:  
Press the HOLD key, Replace the handset, the call will not be terminated. To resume the call, lift the handset (or pick up the call on another phone connected to the same extension).

### **PAUSE FUNCTION**

The "PAUSE" key stores 3.6 seconds pause.