





V5000IP-WiFi User Guide



Tips: When turn around the bracket, it can wall-mounted.

Hold & Resume

- If you want to hold an active call, you can press **Hold** button, and resume it by pressing again.
- You can switch to other lines and hold the active call by pressing **line** button of other lines, and resume it by pressing the **line** button of previous line.

Volume Adjustment

You can adjust the volume in different status with volume button.

Phone Status	Corresponding volume
Standby	Ring volume
Hook off	Handset volume
Hand-free	Speakerphone volume

You can adjust the corresponding microphone input volume as follow:

- Log in WEB management, select "Phone setting">"Basic setting">"Volume setting".

3-way Conference

You can invite the third party into a conference during an active call:

- Press **Conference** button in an active call, dial the third party number, and press **Conference** button again when you have connected the third party.
- When the number of conference members is more than 3, you can make more phones to join the conference and it will become a multiparty conference.

***For more detailed information, you can refer to the corresponding User Manual.**



Hotel Technology International Limited
1st Floor, 239 Kensington High Street, London W8 6SA United Kingdom
Telephone +44 (0) 203 405 1200
Fax: +44 (0) 203 411 6610
E-mail: support@hotel-tech.com
<http://www.hotel-tech.com>

LEDs

Table 1 MUTE Button

LED Status	Description
Lighting-off	Toggles the Mute feature off.
Red, steady	Toggles the Mute feature on.

Table 2 VM Button

LED Status	Description
Lighting-off	No unread voice messages.
Red, steady	Have unread voice messages.

Table 3 Speaker Button

LED Status	Description
Lighting-off	Not to pick up or put a call on hold.
Red, steady	Pick up and enter normal call.

Mounting bracket, telephone access

Network & SIP Account

- **Network:** Press **FLASH** button > Choose "**System setting**" > "**Advanced setting**"> Enter the password required (The default is empty) > Choose "**Wi-Fi Settings**" > **Enable** > Press **Save** soft key.
- **Network:** Press **FLASH** button > Choose "**System setting**" > "**Advanced setting**"> Enter the password required (The default is empty) > Choose "**IP Settings**" > Choose "**Network**"> Press **Save** soft key.
- **SIP Account:** Choose "**System setting**" > "**Advanced setting**"> Enter the password required (The default is empty) > Choose "**SIP Accounts**" > **SIP account 1** > **Enable** > Press **Save** soft key.

Placing a Call

You can pick up the handset or press **Headset/Speaker** button to place a call.

- **Dial directly:** Dial number directly, then press # button;
- **Redial:** Press **Redial** button to dial the latest number;

Answering a Call

- **Answer directly:** You can answer a call by lifting the handset, or pressing the **Speaker** button;

MUTE

- Press **MUTE** button when talking, the voice will be muted on you side and other side cannot hear what you say. If you want to resume, just press again the mute button.